



POLYETHYLENE QUARTER FENDER

Item # 10714

Installation Instructions

Due to the resilient nature of the poly fender it is essential that all mounting instructions be followed.

Lay a straight edge across the truck frame, locate the top of the fender flap a minimum of 2 inches below the top of the fifth wheel to prevent damage to the fender from the trailer.

Allow a minimum of 3 inches clearance between the tire and the fender.

Slide fender all the way onto the mounting post before clamping, the width across the fenders should be 95 inches.

Rotate fender until top flap is near vertical and locate clamp on center of tube slot. Tighten to approximately 150 FT/LBS.

After a shake down run, check all bolts for tightness.

Note

If the polyethylene fender is mounted too close to the bottom of the trailer, it may cause the fender to flex into the tire when the trailer tips and force the top of the fender down. Recommended fender mounting will result in maximum fender and flap life.

