

COOLANT LEVEL SENSOR FOR 2008-2020 FREIGHTLINER CASCADIA

Item Number: 26012

COOLANT LEVEL SENSOR INSTALLATION INSTRUCTIONS

- ① Drain Coolant Reservoir.
- ② Unplug connector from existing Coolant Level Sensor.
- ③ Unscrew the collar nut and remove existing Coolant Level Sensor from the Coolant Reservoir.
- ④ Insert the Coolant Level Sensor into the Coolant Reservoir and tighten the collar nut.
NOTE: Ensure the Coolant Level Sensor sits within the grooves on the mating surface before tightening down the collar nut.
- ⑤ Reconnect the connector onto the new Coolant Level Sensor.
- ⑥ Refill Coolant Reservoir.

