

COOLANT LEVEL SENSOR FOR 2008-2018 VOLVO VNL/VNM

Item Number: 26013

COOLANT LEVEL SENSOR INSTALLATION INSTRUCTIONS

- 1 Drain Coolant Reservoir.
- 2 Disconnect the connector from the existing Coolant Level Sensor.
- 3 Loosen Clamp holding the Coolant Level Sensor to the Coolant Reservoir.
- 4 Remove the Coolant Level Sensor from the Coolant Reservoir.
- 5 Insert the new Coolant Level Sensor into the Coolant Reservoir.
- 6 Tighten Clamp to secure the Coolant Level Sensor to the Coolant Reservoir.
- 7 Reconnect the connector onto the new Coolant Level Sensor.
- 8 Refill Coolant Reservoir.

